

Data Loggers



The ThermaData logger Mk II range offers the customer the choice of either blind data-loggers or data-loggers with a LCD display. Other options include internal and external temperature sensor/probe. The external probes can be either fixed or detachable via a waterproof three-pin connector. The remote temperature probes are supplied with a one metre PVC/PVA lead.

Each logger incorporates a red and green LED, the flashing green LED indicates that the logger is active/logging and the flashing red LED indicates that your customised pre-set alarms have been exceeded. Communications are via a USB cradle that is supplied with the ThermaData Software. Please note: when ordering loggers it is necessary to order at least one ThermaData logger cradle.

specification	ThermaData logger - TD2F
range	-40 to +125°C
resolution	0.1°C
accuracy	±0.5°C
memory	2 x 2,000 readings
sample rate	0.1 to 255 minutes
battery	3.6 volt lithium
battery life	18 months
display	10mm LCD/2 LEDs
dimensions	Ø76 x 23mm
weight	113 grams

For further information please contact

C&M SCIENTIFIC

Parvez Murray

mobile 07894 936 770

email p.murray@cmscientific.co.uk

www.cmscientific.co.uk