



Multi Function Thermometer



This low cost digital Multi-function thermometer is compact and easy to use. The thermometer features an easy to read LCD that displays both the temperature and the alarm set temperatures, ideal for restaurants, bars and cafes as an economical solution for temperature measurement applications.

The thermometer incorporates a display hold facility and a max/min memory function together with an adjustable audible high/low temperature alarm. The unit indicates temperature over the range of -49.9 to +199.9°C with a 0.1°C or 0.1°F resolution.

The rear of the case incorporates a useful foldaway worktop stand, a pocket clip and a probe storage clip. Each unit is supplied with a pointed, stainless steel, penetration probe (Ø3.3 x 125mm) with a one metre PVC connecting lead and probe cover.

For further Information please contact

Parvez Murray
mobile 07894 936 770
email p.murray@cmscientific.co.uk
www.cmscientific.co.uk