

## Temperature Probes



Max-min probe thermometer featuring an easy to read display with display hold and max-min memory functions.

The max-min thermometer measures temperature over the range of -50 to +150°C with a 0.1°C/°F resolution.

The max-min thermometer features a useful fold-away worktop stand. Additionally, this digital max min thermometer incorporates a magnetic pad and a keyhole slot for attaching the unit to an appliance or for wall-mounting. The max-min thermometer is powered by a single MN2400 (AAA) battery with a life expectancy of approximately 5,000 hours.

Now available with re-chargeable battery option

specification	max/min
range	-50 to +150°C
resolution	0.1°C or 0.1°F (switchable)
accuracy	±1°C ±1 digit
battery	1.5 volt AAA
battery life	5,000 hours
sensor type	thermistor
display	12.7 mm LCD
dimensions	20 x 65 x 97mm
weight	100 grams

For further information please contact

Parvez Murray

mobile 07894 936 770

email [p.murray@cmscientific.co.uk](mailto:p.murray@cmscientific.co.uk)

[www.cmscientific.co.uk](http://www.cmscientific.co.uk)