

**Aqua Temp  
CaterTemp Plus waterproof Thermometers**



The CaterTemp Plus hand held thermometer is housed in a robust extruded aluminum waterproof case offering IP66/67 protection. The instrument incorporates the latest microprocessor technology with improved durability, designed for reliability and ease of use in day-to-day catering and food processing applications.

The CaterTemp Plus thermometer measures temperature over the range of -49.9 to +299.9°C with a 0.1°C resolution. The instrument features a large, easy to read, LCD display with open circuit and low battery indication. The unit is powered by a 9 volt battery which gives the thermometer approximately 5,000 hours continuous use.

The on/off button is conveniently located at the front of the instrument as is the display hold facility. The CaterTemp Plus thermometer incorporates a secure battery compartment with a waterproof cover.

Each CaterTemp Plus thermometer is supplied with a permanently attached, water resistant, hand held, food penetration probe with a Ø3.3 x 130mm stainless steel stem and one metre PU coiled lead. The probe is both strong and versatile and suitable for a variety of applications including liquids, semi-solids and granular materials.

specification	AquaTemp 1	AquaTemp 5
range	-49.9 to +199.9°C	-50 to +300°C
resolution	0.1°C	1°C
accuracy	±0.4°C ±1 digit	±1% ±1 digit
battery	12 volt MN21	12 volt MN21
battery life	100 hours	100 hours
sensor type	K thermocouple	K thermocouple
display	12.7 mm LCD	12.7 mm LCD
dimensions	28 x 64 x 148mm	28 x 64 x 148mm
weight	155 grams	155 grams