

## Therma Plus Waterproof Thermometer



The Therma Plus waterproof thermometer is housed in a robust extruded aluminium waterproof case offering IP66/67 protection. The Therma Plus incorporates the latest microprocessor technology with improved durability, designed for reliability and ease of use in routine day-to-day food processing and industrial applications.

The Therma Plus features a large, easy to read, LCD display with open circuit and low battery indication. The Therma Plus thermometer measures temperature over the range of -99.9 to +1372°C, -99.9 to +299.9°C with 0.1°C resolution then auto-ranging to 1°C resolution over the range of +300 to +1372°C.

Now available with re-chargeable battery option!

specification	Therma Plus
measurement temperature range	-99.9 to +1372°C
ambient operating temperature range	-20 to +50°C
resolution	0.1/1°C auto-ranging @ +299.9°C
accuracy	±0.4°C ±0.1% of reading
battery	9 volt PP3
battery life	5,000 hours
sensor type	K thermocouple
display	12mm LCD
dimensions	35 x 60 x 115mm
weight	194 grams

